



GSM/GPRS Mobile Phone

PRO1021 USER MANUAL



Questions?

Need some help?

This manual should help you
understand your new product

If you still have questions
call our help line:
33+(0)4 37 63 29 25



or visit
www.polaroid.com



SAFETY INSTRUCTIONS

Read these safety instructions before using your device and store them for possible future reference.

BATTERY, CHARGER ET ACCESSORIES

If the charger cord is damaged, have it repaired by the manufacturer, its service or a similarly qualified person in order to avoid any hazard.

The charger is not intended for use by persons (including children) with reduced physical, sensory or mental capacity. Persons who have not read the manual, unless they have received explanations by a person responsible for their safety and supervision should not use this unit.

Children should be monitored to ensure that they do not play with the charger.

The charger should always be readily accessible.

The device should not be exposed to dripping or splashing water.

No objects filled with liquids such as vases shall be placed on the device.

Always leave a minimum distance of 10 cm around the unit to ensure sufficient ventilation.

Naked flame sources, such as candles, should not be placed on top of the device.

The device is intended for use only in a temperate climate.

CAUTION: Danger of explosion if battery is incorrectly replaced or not replaced by the same type or equivalent.

The battery should not be exposed to excessive heat such as sunshine, fire or similar.

Different types of batteries, new and used batteries should not be mixed.

The battery must be installed according to the polarity.

If the battery is worn, it must be removed from the product.



The battery must be disposed of safely. Always use the collection bins provided (check with your dealer) to protect the environment.

The European directive 2002/96/EC on Waste Electrical and Electronic Equipment (WEEE), requires that old household electrical appliances must not be disposed of in the normal unsorted municipal

waste stream. It is asked to dispose of them in a repository for this purpose for recycling.

SWITCH OFF IN RESTRICTED AREAS

Switch the phone off where the use of mobile telephones is not allowed or where there is a risk of causing interference or danger, for example on board an aircraft, near medical equipment, fuel, chemicals or blasting sites.

ROAD SAFETY COMES FIRST

Check the current laws and regulations regarding the use of mobile phones in the areas where you drive.

- Do not handle the telephone when driving.
- Concentrate fully on the driving
- Use a hands-free kit whenever possible
- Leave the road and park up before making or receiving a call, if the driving conditions allow.
- Radio signals could affect some of the car's electronic systems such as the audio stereo and alarm systems.
- If the car is equipped with an airbag, do not hinder its deployment with fixed or wireless equipment. This could result in serious injury due to inadequate performance.

INTERFERENCE

All wireless devices are susceptible to interference which may affect their performance.

AUTHORISED PERSONNEL

Only qualified people are authorised to install or repair this product

ACCESSORIES

Only use batteries, chargers and other accessories which are compatible with this equipment. Do not connect incompatible products.

KEEP THE EQUIPMENT DRY

This equipment is not water proof. Keep it dry.

CHILDREN

Keep your phone in a safe place, out of the reach of young children. The telephone contains small parts that may present a choking hazard.

EMERGENCY CALLS

Emergency numbers may not be available on all cellular networks. Therefore you shouldn't solely depend on the mobile phone to make an emergency call. Check with your local service provider.

Precautions for use

This mobile phone meets guidelines concerning the exposure to radio waves.

Your mobile phone is a radio transmitter and receiver. It was designed to meet the limits recommended by international guidelines to limit the exposure to radio waves. These guidelines were developed by and independent scientific organisation, The ICNIRP; and include safety margins designed to ensure the protection of all, regardless of age and health.

The recommendations on exposure guidelines for mobile phones employ a unit of measure known as the Specific absorption rate or SAR. The SAR limit defined in the ICNIRP recommendations is 2.0 watts/kilogramme (W/kg) averaged over 10 grams of tissue. In tests to determine the SAR, the equipment is used in standard usage positions at its highest certified power level in all tested frequency bands. The actual SAR level of a device in use may be lower than the maximum value because the equipment is designed to only use the necessary power required to reach the network. That amount changes depending on a number of factors such as the distance from a network base station.

Radio frequency interference

Radio frequency output from electronic devices can interfere with other electronic equipment and cause malfunctions. Although this phone has been designed in accordance with EU regulations on radio frequency emission, telephone wireless transmitters and electrical circuits can cause interference with other electronic equipment. We therefore recommend taking the following precautions :

Aircraft : Wireless equipment can cause interference in aircraft.

- Turn off your telephone before boarding the aircraft
- Do not use on the ground until allowed to do so by the flight crew.

Vehicles : Telephone radio frequency emissions can affect the electronic systems of motor vehicles. In relation to your vehicle, check with the manufacturer or dealer.

Medical implants :

Medical equipment manufacturers recommend a minimum distance of 15 centimetres between a wireless device and an implanted medical device such as a pacemaker or defibrillator to avoid any interference with the medical device. It is recommended that people

fitted with such devices :

- Always keep wireless equipment more than 15cm away from the medical device.

- Never carry wireless equipment in a breast pocket.

- Place such equipment at the opposite ear to the medical device.

- Turn off the wireless equipment if they think it is interfering with their device

- Follow the instructions provided by the medical implant manufacturer.

If you are fitted with a medical implant and have any questions related to the use of your mobile/wireless equipment, you should consult your doctor

Hearing :

Warning: Using a headset risks not be able to correctly hear outside sounds. Do not use a headset when it could endanger your safety. Some mobile devices can interfere with the proper operation of hearing aids.

Other medical devices :

Radio transmitting equipment including mobile phones may interfere with the proper operation of insufficiently protected medical equipment. Consult a doctor or the medical equipment manufacturer to find out whether the equipment is sufficiently protected from external radio wave signals. Turn off your device where required by regulations, particularly in hospitals.

Health facilities: Hospitals and health facilities may be using equipment which is particularly sensitive to external radio frequency emissions. Turn off the telephone when staff or notices tell you to.

Blasting sites and marked areas:

Turn off your device in potentially explosive areas. Follow all official instructions. Sparks in such areas can cause an explosion or a fire, resulting in serious injury or death. Turn off your equipment in petrol/gas stations, especially when near the fuel pumps. Strictly follow usage restrictions in fuel depots, chemical plants or in places using explosives.

Potentially explosive areas are often, but not always, clearly signed. These include areas where it is normally considered advisable to turn off vehicle engines, the area below deck on ships, chemical storage or

transfer plants, and areas where the air contains chemical products or particles, such as grain, dust and metal powder. Check with the makers of LPG (such as propane or butane) vehicles that the device can be used safely in their vicinity.

All our phones conform to international standards and regulations, and if need be national ones, with a view to limiting user exposure to electromagnetic fields. These standards and regulations were adopted after the completion of extensive scientific research. This research established no link between the use of the mobile phone and any adverse effects on health if the device is used in accordance with standard practices.

However if you would like to reduce the level of exposure to radio frequency radiation you can follow the following rules:

- Call when reception conditions are good to lessen the amount of radiation. To do this, avoid calling from underground car parks or when travelling by train or car.
- Call when the telephone connection is at its best (displayed by maximum bars of network reception)
- Use a hands-free kit to ensure the phone is kept away from pregnant women's bellys and adolescents' lower abdomens.

Operating environment

This equipment conforms to the recommendations on the exposure to radio waves when it is used in its normal position next to the ear or at a minimal distance of 1.5cm. When a case, belt clip or holder is used to carry the phone on the body, these should not contain metal and should position the equipment slightly away from the body.

Sending data files or messages requires a good quality network connection. The sending of files or messages can be delayed until such a connection becomes possible. Follow the instructions according to the delay as the transmission hasn't been achieved.

Compliance Statement

Hereby, Market Maker Brand Licensing declares that the appliance [ref article] complies with the essential requirements and other relevant provisions of Directive 1999/5/CE. The declaration of conformity can be viewed at the following address:

Market Maker Brand Licensing
81 ART NATIONALE 7
69570 DARDILLY - FRANCE

Chapter 1 Phone Introduction

1.1 SIM Card

Before you use your phone, you must insert your SIM card. It's your key to enter into the GSM network.

1.2 Battery


The new battery needs to be charged for at least 5 hours for the first time even though the battery displays fully. Since the second time, just charge the battery until you see the sign on the display is full.

1.3 Power on/off

Press and hold the Power Key to turn on/off the phone.

*Note: if "Emergency number" appears, it means you are out of the service area of the network. But you can still make emergency calls.

1.4 Statusicons



Chapter 2 Menu Details

2.1 Message

u Write Message: SMS / MMS(no bigger than 100KB, before using MMS, we must choose the correct Profile – Network provider first.)

- u Inbox
- u Outbox
- u Drafts
- u Sentbox
- u Delete message

2.2 Contacts / Phonebook

Users can view contacts / Search a contact/ edit the contacts / delete the contacts / Call the contacts / Send Message to the contacts / Copy the contacts / Move the contacts;

Users can also set groups for different contacts.

In this function, users can check the memory status of both SIM and phone.

2.3 Call logs

I Call history:

Dialed calls / Received calls / Missed calls

I Delete calls from Dialed calls / Received calls / Missed calls; or

delete all.

- I Call timers

2.4 Settings

- I SIM modes: Dual SIM open / Only SIM1 open / Only SIM2 open;
- I Phone setting: Time& Date / Scheduled Power ON & OFF / Languages / Default Input / Wall paper / Screen saver / Key definitions / LCD backlight settings.
- I Internet: Network selection / Preferences
- I Security Setting: SIM lock / Phone Lock / Keypad lock / Change Password.
- I Connectivity: Bluetooth / Data Account
- I Restore Factory Default, Password: 1122

2.5 Multimedia

- u Image Viewer: support JPG, GIF picture browser.
- u Audio player

This mobile phone is able to play audio formats of MP3, MIDI

- u Video player

This mobile phone is able to play video formats of MP4, 3GP

- u FM radio

This mobile phone supports FM radio. Please plugin earphone before using.

u Camera, this phone configured with a VGA camera on the back.

Camera options

Option	Description
Self mode	Activate/deactivate the front camera
To album:	View the saved pictures and the “+/-” on the screen are invalid.
Camera settings	Shutter tone: Sound effect I, II, III and OFF
	Exposure compensation: -4 ~ +4
	Avoid flicker: 50Hz (default), 60Hz
	Shooting delay: 5sec, 10sec, 15sec or OFF.
Image setting	Sequence setting: Single, three, five or OFF.
	Image size: 640*480, 320*240, 160*120, 240*180
White balance	Image quality: intermediate, high, low
Scene mode	Auto, sunlight, tungsten lamp, fluorescent, cloudy, and incandescent.
Special effect setting	Auto, night mode
Image frame	Five options are available
Storage path	Two options are available and you can also disable the image frame
Reset	Memory card
	Restore the default settings

2.6 File Manager

Insert Micro SD Card to browse all files.

2.7 Fun & Games

It has build-in games with Help function.

- I E-Book reader
- I Game – Sokoban

2.8 Profiles

Standard / Silent / Meeting / Outdoor / My profile.

Users can set ringtones, Tone volume, Alert type, Ring type, Answer mode.

2.9 Tools

- u Calendar
- u Alarm
- u Calculator
- u Torch light: Press and hold “OK” key to switch on the Torch light; press and hold again to switch off.

2.10 Attention:

- u Do not approach the phone to Fire, Water, Liquid, Static.
- u Keep the phone away from dusty and dirty.
- u Don't drop, crash the phone.
- u Unpainted.
- u User the original battery and charger for your safety.
- u Don't open the phone if you have any trouble, turn to our technician for help.

Chapter 3 Trouble shooting

Failure	Reason
Can't switch on	1 ? The battery has been run out; 2 ? The battery isn't installed properly.
SIM card error	1 ? SIM card is dirty. Clean the SIM card. 2 ? Re-install the SIM card. 3 ? SIM card is damaged. Please change a new one. 4 ? (SIM2 is same)
Weak signal	Check the icon of signal strength, where four strips indicate the strongest signal and two or less strips indicate weak signal. (SIM2 is same)
Can't make calls	(I) You have set to hide your own number, but the network operator doesn't support this service. (II). The ambient has strong interference. (III). You have enabled call barring. (IV). You have activated Line 2, but the network operator doesn't support this service.
Can't charge the battery	(I). The battery may be over discharged and it takes a while to charge after connected to the charger. (II) Battery performance has decreased.
Can't connect to network	(I). The signal is too weak, or there is radio interference. (II). Check whether the SIM card is installed properly, whether the contact is poor or whether the card is damaged? Please contact your network operator if the SIM card is damaged.
The photos taken are too dark	(I) The brightness is too low; (II) The environment is too dark

The photos taken are blurry	(I) The object is moving; (II) Your hand shakes when you press the shutter
The photos taken are distorted	The object is too close
Can't access service menu	The SIM card doesn't support

Chapter 4 Technical specification

General	Network	Dual-band: GSM 900 / 1800
	SIM	Dual SIM
Size	Dimensions	107*58.5*12.5MM
	Weight	AROUND 80G (with battery)
Display	Type	QCIF , 65k COLOR
	Size	2.0Inches; resolution: 176*220
Sound	Alert types	Polyphonic (MIDI, MP3 formats)
	Speakerphone	Yes
	Earphone Jack	YES
Memory	Phonebook	200 records
	Call records	20 dialed calls, 20 missed calls,20

		received calls
	Internal	64Mb NAND
	Card slot	MicroSD (TransFlash), up to 16GB

Data	GPRS	YES
	Infrared port	NO
	USB	Micro 5-PIN USB
Camera	Camera	Yes, back VGA camera
Features	CPU	MTK6252
	Languages	Max 4 languages
	Messaging	SMS, MMS
	Call transfer	YES
	Browser	YES , WAP
	Radio	YES
	Bluetooth	YES
	Games	YES, 1-2 games
	Colors	Black, silver
	Java	NO
	Video	AVI, MP4, 3GP
	Music	MIDI, MP3
	Picture	JPG, GIF

	Others	Alarm; Calculator; Calendar; World Time; Auto power on/off; Keypad Lock.
SAR	GSM900	1.486W/Kg
	GSM1800	0.867W/Kg
Battery life	Capacity	600mAh
	Stand-by	Up to 200 hrs
	Talk time	Up to 4 hrs
	Kind of Battery	Rechargeable battery LI-Ion 3.7V
Charger technical data		INPUT : AC 100V - 240V- 50~60Hz, 0.5A OUTPUT : DC5V

PLR IP Holdings, LLC, its licensees and affiliates, fully support all electronic waste initiatives. As responsible stewards of the environment, and to avoid violating established laws, you should properly dispose of this product in compliance with all applicable regulations, directives or other governances in the area where you reside. Please check with local authorities or the retailer where you purchased this product to determine a location where you can appropriately dispose of the product.

THE DISPOSAL OF ELECTRICAL AND ELECTRONIC EQUIPMENT WASTE PRODUCTS ON THE PART OF FINAL USERS IN THE EUROPEAN UNION

This symbol on the product or on the container indicates that this product cannot be eliminated with the general waste. The user is responsible for eliminating this kind of waste by throwing them away at a "recycling point" specifically for electrical and electronic waste. Selective collection and electrical equipment recycling contribute to preserve natural resources and warrant waste recycling to protect environment and health. In order to receive further information about electrical and electronic waste collecting and recycling, contact your

Local Council, the service of household waste or the establishment where the product was acquired.



At full volume, prolonged listening to the portable audio device may damage the user's hearing.

Polaroid and Polaroid & Pixel are trademarks of PLR IP Holdings, LLC, used under license. All other trademarks are the property of the respective owner, who has not sponsored, endorsed or approved this product. PLR IP Holdings, LLC does not manufacture this product or provide any Manufacturer's warranty or support.

Copyright © 2011. All rights reserved. This product is manufactured, distributed,

and sold by Market Maker Brand Licensing, 79 route nationale 7, 69570 Dardilly, France

For warranty information and technical support, please call 33 + (0)4
37 63 29 25 or visit www.polaroid.com.

Product features, specifications and appearances are subject to
change without notice.

